

Danger

Safety Data Sheet

Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091 Issue date: 5/29/2019 Revision date: 8/30/2023 Supersedes version of: 8/21/2023 Version: 1.2

SECTION 1: Identification of the substance/mixture and of the company/undertaking

1.1. Product identifier	
Trade name	: Nitrogen trifluoride
SDS no	: D-NF3-091
Other means of identification	: Nitrogen trifluoride
	CAS-No. : 7783-54-2
	EC-No. : 232-007-1
	EC Index-No. :
REACH registration No	: 01-2119962459-23
Chemical formula	: NF3
1.2. Relevant identified uses of the substan	nce or mixture and uses advised against
Relevant identified uses	: See the list of identified uses and exposure scenarios in the annex of the safety data sheet.
	Perform risk assessment prior to use.
Uses advised against	: Consumer use.
	Uses other than those listed above are not supported, contact your supplier for more
	Uses other than those listed above are not supported, contact your supplier for more information on other uses.
1.3. Details of the supplier of the safety data	information on other uses.
1.3. Details of the supplier of the safety data Messer Industriegase GmbH	information on other uses.
	information on other uses.
Messer Industriegase GmbH	information on other uses.

1.4. Emergency telephone number

Emergency telephone number

: Messer Produktionsgesellschaft mbH Salzgitter, +49 (0) 5341 21-9333, erreichbar Montags 0:00 bis Sonntags 24:00

SECTION 2: Hazards identification

2.1. Classification of the substance or mixture

T +49 (0) 6196 7760-200 - F +49 (0) 6196 7760-280 SDB.de@messergroup.com - www.messer.de

Classification according to Regulation (EC) No. 1272/2008 [CLP]

Physical hazards	Oxidising Gases, Category 1	H270
	Gases under pressure : Liquefied gas	H280
Health hazards	Acute toxicity (inhalation:gas) Category 4	H332
	Specific target organ toxicity – Repeated exposure, Category 2	H373



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

2.2. Label elements

Labelling according to Regulation (EC) No. 1272/2008 [CLP]

Hazard pictograms (CLP)	GHS03 GHS04 GHS07 GHS08
Signal word (CLP)	: Danger
Hazard statements (CLP)	: H270 - May cause or intensify fire; oxidiser.
	H280 - Contains gas under pressure; may explode if heated.
	H332 - Harmful if inhaled.
	H373 - May cause damage to organs through prolonged or repeated exposure.
Precautionary statements (CLP)	
- Prevention	: P260 - Do not breathe gas, vapours.
	P244 - Keep valves and fittings free from oil and grease.
_	P220 - Keep away from clothing and other combustible materials.
- Response	: P304+P340+P315 - IF INHALED : Remove victim to fresh air and keep at rest in a position comfortable for breathing. Get immediate medical advice / attention.
	P370+P376 - In case of fire: Stop leak if safe to do so.
- Storage	: P403 - Store in a well-ventilated place.
2.3. Other hazards	
	Contact with liquid may cause cold burns/frostbite.
	The substance/mixture has no endocrine disrupting properties.

SECTION 3: Composition/information on ingredients

3.1. Substances

Name	Product identifier	%	Classification according to Regulation (EC) No. 1272/2008 [CLP]
Nitrogen trifluoride	CAS-No.: 7783-54-2 EC-No.: 232-007-1 EC Index-No.: REACH registration No: 01-2119962459- 23	100	Ox. Gas 1, H270 Press. Gas (Liq.), H280 Acute Tox. 4 (Inhalation:gas), H332 STOT RE 2, H373

Contains no other components or impurities which will influence the classification of the product. Not applicable

3.2. Mixtures

SECTION 4: First aid measures

4.1. Description of first aid measures	
- Inhalation	 Remove victim to uncontaminated area wearing self contained breathing apparatus. Keep victim warm and rested. Call a doctor. Perform cardiopulmonary resuscitation if breathing stopped.
- Skin contact	: In case of frostbite spray with water for at least 15 minutes. Apply a sterile dressing. Obtain medical assistance.
- Eye contact	: Immediately flush eyes thoroughly with water for at least 15 minutes.
- Ingestion	: Ingestion is not considered a potential route of exposure.



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

4.2. Most important symptoms and effects, both acute and delayed

Delayed adverse effects possible.

Prolonged or repeated exposure may affect the red blood cells and haemoglobin. See section 11.

4.3. Indication of any immediate medical attention and special treatment needed

Obtain medical assistance.

SECTION 5: Firefighting measures	
5.1. Extinguishing media	
- Suitable extinguishing media	: Water spray or fog. Product does not burn, use fire control measures appropriate for the surrounding fire.
- Unsuitable extinguishing media	: Do not use water jet to extinguish.
5.2. Special hazards arising from the substance	or mixture
Specific hazards	: Supports combustion. Exposure to fire may cause containers to rupture/explode.
Hazardous combustion products	: Hydrogen fluoride. Nitric oxide/nitrogen dioxide.
5.3. Advice for firefighters	
Specific methods Special protective equipment for fire fighters	 Use fire control measures appropriate for the surrounding fire. Exposure to fire and heat radiation may cause gas receptacles to rupture. Cool endangered receptacles with water spray jet from a protected position. Prevent water used in emergency cases from entering sewers and drainage systems. If possible, stop flow of product. Use water spray or fog to knock down fire fumes if possible. Move containers away from the fire area if this can be done without risk. Wear gas tight chemically protective clothing in combination with self contained breathing
	 Wear gas tight chemically protective clothing in combination with self contained breathing apparatus. Standard EN 943-2: Protective clothing against liquid and gaseous chemicals, aerosols and solid particles. Gas-tight chemical protective suits for emergency teams. Standard EN 137 - Self-contained open-circuit compressed air breathing apparatus with full face mask.

SECTION 6: Accidental release measures

6.1. Personal precautions, protective equipment and emergency procedures

: Act in accordance with local emergency plan.
Try to stop release.
Evacuate area.
Eliminate ignition sources.
Ensure adequate air ventilation.
Prevent from entering sewers, basements and workpits, or any place where its
accumulation can be dangerous.
Stay upwind.
See section 8 of the SDS for more information on personal protective equipment.
: Monitor concentration of released product.
Wear self-contained breathing apparatus when entering area unless atmosphere is proved
to be safe.
See section 5.3 of the SDS for more information.

Try to stop release.

6.3. Methods and material for containment and cleaning up

Ventilate area.



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

6.4. Reference to other sections

See also sections 8 and 13.

Avoid release of product into work area. For more guidance on safe use, refer to the EIGA Doc.92 "Code of practice Nitrogen trifluoride", downloadable at http://www.eiga.org, and consuit your suppler. The product must be handled in accordance with good industrial hygiene and selety procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure reliad device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use no oil or grease. Use on lor operly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only toperly specified equipment for the specific gas service. Befer to supplier's container handling instructions. Do not allow backfeed in the container. Protect containers from physical damage; do not drag, noll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container valve or sleety relief devices. Damaged valves should be reported immediately to the supplier. Never attempt to transfer gases from one cylinder/containin to sand avide a soon as contain is disconnected from equipment. Close container valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve subter clencian hereiting bervices. Do not remove or deface labels provided by the supplier for the identification of the container. Do not remove or deface labels provided by the supplier for the ide	7.1. Precautions for safe handling	
For more guidance on safe use, refer to the EIGA Doc S2 "Code of practice Nitrogen trifluoride", downloadable at http://www.eiga.org. and consult your supplier. The product must be handled in accordance with good industrial hygiene and safety procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularity) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubicants and sealings approved for the specific gas service. Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, noll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safet prelied devices. Damaged valves bould be able provided by the supplier for the identification of the container Reeplace valve outet cags or plugs and container caps where supplied as soon as contain is disconnected from equipment. Coste or valve slowly to avoid pressure shock. 7.2 Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observer all regulations and l	Safe use of the product	: Do not breathe gas.
 titliuorida⁺, downloadable at http://www.eiga.org. and costally your supplier. The product must be handled in accordance with good industrial hygiene and safety procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkais. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkais. Use only lubricants and sealings approved for the specific gas service. Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage: do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready role and contact supplier. Never atternpt to repair or modity container valves or safety relief devices. Damaged valves should be perponded medicately to the supplier. Never use direct frame or electrical heating devices to raise the pressure and is directly relief and sore addy relief. Suck back of water in the container must be	·	-
The product must be handled in accordance with good industrial hygiene and safety procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use on oil or grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only uproperly specified ealings approved for the specific gas service. Bo not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the containine has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to be reported inmediately to the supplier. Keep container valve advected to equipment. Container valve advected to equipment. Container valve advected to a program of advected to equipment. Container valve advectails hasting devices to raise the pressure of a container. Never us direct thare or electrical hasting devices to raise the pressure of a container sof the container. Suck back of valver i		
The product must be handled in accordance with good industrial hygiene and safety procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use on oil or grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only uproperly specified ealings approved for the specific gas service. Bo not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the containine has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to transport cylinders. Leave valve protection caps in place until the containiner has been secured against either a wall or bench or placed to be reported inmediately to the supplier. Keep container valve advected to equipment. Container valve advected to equipment. Container valve advected to a program of advected to equipment. Container valve advectails hasting devices to raise the pressure of a container. Never us direct thare or electrical hasting devices to raise the pressure of a container sof the container. Suck back of valver i		
 procedures. Only experienced and properly instructed persons should handle gases under pressure. Consider pressure reliaf device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. A void exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 · Cleaning of Equipment for for noil and grease. For more guidance, refer to the EIGA Doc. 33 · Cleaning of Equipment to for yong Service downloadable at http://www.eiga.eu. Use on 0/1 or grease. Use on 0/1 ubricants and sealings approved for the specific gas service. Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, side or drop. When moving cylinders, work on for that distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container valves or safty reliaf devices. Damaged valves should be reported immediately to use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to transfor gases from one cylinders. Damaged valves should be reported immediately to use. If user each use and when empty, even if still connected to equipment. Close container valve outlet caps or plugs and container barchould oil and valve. Never use direct fitting or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Segregate from fammable gases and other fammable ma		
 Only experienced and properly instructed persons should handle gases under pressure. Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment tor Oxygen Service downloadable at http://www.eiga.eu. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only ubricants and seelings approved for the specific gas service. E Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage: do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in mediately to the supplier. Never attempt to repair or modify container valves or safety reliaf devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from container staps particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve outlets clean and the metry, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct fame or electrical heating devices to raise the pressure of a container salve there		
Consider pressure relief device(s) in gas installations. Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use noil or grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Before to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve storediscultary oil and water. Reeptace valve protection caps in place until the container wase or safety relief devices. Damaged valves should be reported immediately to the supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Never attempt to transfer gases from one cylinder/container to another. Never attempt to transfer gases from one cylinder/container to another. Never attempt to transfer gases from noe cylinder/container to another. Never use direct filme or relating divices to raise the pressure of a container. Do not remove or deface labels provided by the supplier to the identification of the container. Do not remove or deface labels provided by the supplier to the identification of the container. Suck back of vater into the container must be pr		•
Ensure the complete gas system was (or is regularily) checked for leaks before use. Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use no oil or grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doub. Avoid suck back of water, acid and alkalis. Use only lubricents and sealings approved for the specific gas service. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand use us of standy for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Never valve slowly to avoid pressure should. 7.2 Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should ho te stored in container should be in place. Containers should ho te stored in chevitel position and properly secured t		
Do not smoke while handling product. Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 - Cleaning of Equipment for Coxygen Service downloadable at http://www.eiga.eu. Use no oil or grease. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Refer to supplier's container handling instructions. Do not allow backdee dino the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or place in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outer cleaps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier of the identification of the container. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container of the container. Suck back of water into the con		
Avoid exposure, obtain special instructions before use. Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 3 - Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use no oil or grease. Use on oil or grease. Use on oil or grease. Use on oil or grease. Use on oil or grease. Sate handling of the gas receptacle Refer to supplier's container handling instructions. Do not allow backded on the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a the container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damage valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Containers should be stored in conditions likely to encourage corrosion. Containers should be beroid in the vertical p		
Keep equipment free from oil and gresse. For more guidance, refer to the EIGA Doc. 33 - Clearing of Equipment Or Oxygen Service downloadable at http://www.eiga.eu. Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only ubricants and sealings approved for the specific gas service. safe handling of the gas receptacle Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as scon as contain is disconnected from equipment. Close container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as scon as contain is disconnected from equipment. Do not remove or deface labels provided by the supplier for the identification of the container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate		
Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu. Use no oil or grease. Use on y properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficutly operating valve discontinue use and contact supplier. Never attempt to repair or modify container stand and is ready for use. If user experiences any difficutly operating valve discontinue use and contact supplier. Never attempt to repair or modify container caps where supplied as soon as contair is disconnected from equipment. Close container valve outlet caps or plugs and container pass where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2 Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Containers should he stored in conditions likely to encourage corrosion. Container valve guards or caps should to encluage corrosion. Containers should h		
Use on oil or grease. Use only uproperly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Bafe handling of the gas receptacle Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve atter each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Containers should not be stored in conditions likely to encourage corrosion. Containers should hor be stored in conditions flavely to encourage corrosion. Containers should hor be stored in conditions and preperly secured to prevent them from falling over. Stored containers should be preiodicaly tocke		
Use only properly specified equipment which is suitable for this product, its supply pressu and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. E Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Reep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Containers should not be stored in conditions likely to encourage corrosion. Containers should not be stored in conditions inkely to encourage corrosion. Containers should be periodically tockcekef or general conditions and leakage. Keep containers should be stored in the vertical position and properly secured to prevent them from fal		
and temperature. Contact your gas supplier if in doubt. Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Safe handling of the gas receptacle : Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safery relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container. De not remove or deface labels provided by the supplier for the identification of the conte of the container. Do not remove or deface labels provided by the supplier for the identification of the conte of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should not be stored in the vertical position and properly secured to prevent them from falling over. Stored containers in location free from fire risk and away from sources of heat and ignition		-
Avoid suck back of water, acid and alkalis. Use only lubricants and sealings approved for the specific gas service. Safe handling of the gas receptacle : Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and there from contaminants particularly oil and water. Replace valve outlet caps or plugs and container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Never use direct flame or electrical heating devices to raise the pressure of a container. Never use direct flame or electrical heating devices to raise the pressure of a container. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the contain of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions flikely to encourage corrosion. Container valve guards or caps should be in place. Containers should hot be periodically checked for general condition and leakage. Keep containers should be per		
Use only lubricants and sealings approved for the specific gas service. Safe handling of the gas receptacle 2 Refer to supplier's container handling instructions. Do not allow backfeed in the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should not be stored in the vertical position and properly secured to prevent them from falling over. Store containers should be periodically checked for general condition and leakage. Keep containers in location free from fire risk and away from sources of heat and ignition		
Safe handling of the gas receptacle : Refer to supplier's container handling instructions. Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container to another. Never attempt to transfer gases from one cylinder/container to another. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of conta		
Do not allow backfeed into the container. Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve dutlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container should be tored in condition likely to encourage corrosion. Containers should not be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep con	Safe handling of the gas recentacle	
Protect containers from physical damage; do not drag, roll, slide or drop. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the contein of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Containers should not be stored in place. Containers should be stored in place. Containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general c	bare nanuling of the gas receptable	
When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containerer valve gaveds or caps should be in place		
designed to transport cylinders. Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the contein of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should not be stored in the vertical position and properly secured to prevent them from falling over. Store dontainers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers should be periodically checked for general condition and leakage. Keep containers in location free from fire risk and away from sources of heat and ignition.		
Leave valve protection caps in place until the container has been secured against either a wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Store containers should be periodically checked for general condition and leakage. Keep container should be periodically checked for general condition and leakage. Keep containers in location free from fire risk and away from sources of heat and ignition.		
 wall or bench or placed in a container stand and is ready for use. If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Containers should be stored in conditions likely to encourage corrosion. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
If user experiences any difficulty operating valve discontinue use and contact supplier. Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conte of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Store containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place.		
Never attempt to repair or modify container valves or safety relief devices. Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contair is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep containers in location free		
Damaged valves should be reported immediately to the supplier. Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conte of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers blow 50°C in a well ventilated place. Keep containers in location free from fire risk and away from sources of heat and ignition.		
Keep container valve outlets clean and free from contaminants particularly oil and water. Replace valve outlet caps or plugs and container caps where supplied as soon as contain is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conte of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be speriodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Replace valve outlet caps or plugs and container caps where supplied as soon as container is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition		•
is disconnected from equipment. Close container valve after each use and when empty, even if still connected to equipment. Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conter of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container should not be stored in conditions likely to encourage corrosion. Container should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place.		
Close container valve after each use and when empty, even if still connected to equipment Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conter of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place.		
Never attempt to transfer gases from one cylinder/container to another. Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the conter of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Never use direct flame or electrical heating devices to raise the pressure of a container. Do not remove or deface labels provided by the supplier for the identification of the contere of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Do not remove or deface labels provided by the supplier for the identification of the conten- of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
of the container. Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Suck back of water into the container must be prevented. Open valve slowly to avoid pressure shock. 7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
7.2. Conditions for safe storage, including any incompatibilities Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		·
Segregate from flammable gases and other flammable materials in store. Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Observe all regulations and local requirements regarding storage of containers. Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.	2.2. Conditions for safe storage, including	any incompatibilities
Containers should not be stored in conditions likely to encourage corrosion. Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Container valve guards or caps should be in place. Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Containers should be stored in the vertical position and properly secured to prevent them from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		Containers should not be stored in conditions likely to encourage corrosion.
from falling over. Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		
Stored containers should be periodically checked for general condition and leakage. Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		Containers should be stored in the vertical position and properly secured to prevent them
Keep container below 50°C in a well ventilated place. Store containers in location free from fire risk and away from sources of heat and ignition.		from falling over.
Store containers in location free from fire risk and away from sources of heat and ignition		Stored containers should be periodically checked for general condition and leakage.
		Keep container below 50°C in a well ventilated place.
		Store containers in location free from fire risk and away from sources of heat and ignition.
	3.3. Specific end use(s)	

None.



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

SECTION 8: Exposure controls/personal protection

8.1. Control parameters

Nitrogen trifluoride (7783-54-2)	
DNEL: Derived no effect level (Workers)	
Acute - local effects, inhalation	44 mg/m ³
Acute - systemic effects, inhalation	44 mg/m ³
Long-term - local effects, inhalation	29 mg/m ³
Long-term - systemic effects, inhalation	29 mg/m ³

PNEC (Predicted No-Effect Concentration)

: None established.

8.2. Exposure controls

8.2.1. Appropriate engineering controls

	Provide adequate general and local exhaust ventilation. Product to be handled in a closed system. Systems under pressure should be regularily checked for leakages. Ensure exposure is below occupational exposure limits (where available). Gas detectors should be used when toxic gases may be released. Consider the use of a work permit system e.g. for maintenance activities.
8.2.2. Individual protection measures, e.g. p	ersonal protective equipment
	A risk assessment should be conducted and documented in each work area to assess the risks related to the use of the product and to select the PPE that matches the relevant risk. The following recommendations should be considered: PPE compliant to the recommended EN/ISO standards should be selected.
Eye/face protection	: Wear goggles when transfilling or breaking transfer connections. Standard EN 166 - Personal eye-protection - specifications.
Skin protection	
- Hand protection	 Wear working gloves when handling gas containers. Standard EN 388 - Protective gloves against mechanical risks, performance level 1 or higher. Standard EN 511 - Cold insulating gloves.
- Other	 Consider the use of flame resistant safety clothing. Standard EN ISO 14116 - Limited flame spread materials. Wear safety shoes while handling containers. Standard EN ISO 20345 - Personal protective equipment - Safety footwear.
Respiratory protection	 Self contained breathing apparatus (SCBA) or positive pressure airline with mask are to be used in oxygen-deficient atmospheres. Keep self contained breathing apparatus readily available for emergency use. Self contained breathing apparatus is recommended, where unknown exposure may be expected, e.g. during maintenance activities on installation systems. Standard EN 137 - Self-contained open-circuit compressed air breathing apparatus with full face mask. Consult respiratory device supplier's product information for the selection of the appropriate device.
Thermal hazards	: None in addition to the above sections.
8.2.3. Environmental exposure controls	
	Refer to local regulations for restriction of emissions to the atmosphere. See section 13 for



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

SECTION 9: Physical and chemical properties

9.1. Information on basic physical and chemical properties

Appearance	
 Physical state at 20°C / 101.3kPa 	: Gas.
- Colour	: Colourless.
Odour	: Mouldy.
Melting point / Freezing point	: -207 °C
Boiling point	: -129 °C
Flammability	: Non flammable.
Lower explosion limit	: Not applicable.
Upper explosion limit	: Not applicable.
Flash point	: Not applicable for gases and gas mixtures.
Auto-ignition temperature	: Non flammable.
Decomposition temperature	: Not applicable.
рН	: Not applicable for gases and gas mixtures.
Viscosity, kinematic	: No reliable data available.
Water solubility [20°C]	: 61 mg/l
Partition coefficient n-octanol/water (Log Kow)	: Not applicable for inorganic products.
Vapour pressure [20°C]	: Not applicable.
Vapour pressure [50°C]	: Not applicable.
Density and/or relative density	: Not applicable for gases and gas mixtures.
Relative vapour density (air=1)	: 2.4
Particle characteristics	: Not applicable for gases and gas mixtures.
	Nanoforms are not relevant for gases and gas mixtures.

9.2. Other information

9.2.1. Information with regard to physical h	azard classes
Oxidising properties	: Oxidiser.
 Coefficient of oxygen equivalency (Ci) 	: 1.6
Critical temperature [°C]	: -39 °C
9.2.2. Other safety characteristics	
Molar mass	: 71 g/mol
Other data	: Gas/vapour heavier than air. May accumulate in confined spaces, particularly at or below ground level.

SECTION 10: Stability and reactivity	
10.1. Reactivity	
	No reactivity hazard other than the effects described in sub-sections below.
10.2. Chemical stability	
	Stable under normal conditions.
10.3. Possibility of hazardous reactions	
	Violently oxidises organic material.
10.4. Conditions to avoid	
	Avoid moisture in installation systems.

10.5. Incompatible materials

May react violently with combustible materials.
May react violently with reducing agents.
Keep equipment free from oil and grease. For more guidance, refer to the EIGA Doc. 33 -
Cleaning of Equipment for Oxygen Service downloadable at http://www.eiga.eu.
For additional information on compatibility refer to ISO 11114.



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

10.6. Hazardous decomposition products

Under normal conditions of storage and use, hazardous decomposition products should not be produced.

SECTION 11: Toxicological information

11.1. Information on hazard classes as defined in Regulation (EC) No 1272/2008

Acute toxicity	: Harmful if inhaled.
LC50 Inhalation - Rat [ppm]	3350 ppm/4h
Skin corrosion/irritation	: No known effects from this product.
Serious eye damage/irritation	: No known effects from this product.
Respiratory or skin sensitisation	: No known effects from this product.
Germ cell mutagenicity	: No known effects from this product.
Carcinogenicity	: No known effects from this product.
Toxic for reproduction : Fertility	: No known effects from this product.
Toxic for reproduction : unborn child	: No known effects from this product.
STOT-single exposure	: Damage to red blood cells (haemolytic poison).
STOT-repeated exposure	 Prolonged or repeated exposure may affect the red blood cells and haemoglobin. May cause damage to organs through prolonged or repeated exposure.
Target organ(s)	: heart. liver. blood.
Aspiration hazard	: Not applicable for gases and gas mixtures.
11.2. Information on other hazards	
Other information	: The substance/mixture has no endocrine disrupting properties.

SECTION 12: Ecological information

12.1. Toxicity : No ecological damage caused by this product. Assessment EC50 48h - Daphnia magna [mg/l] : No data available. EC50 72h - Algae [mg/l] : No data available. LC50 96 h - Fish [mg/l] : No data available. 12.2. Persistence and degradability : Not applicable for inorganic products. Assessment Study scientifically unjustified. 12.3. Bioaccumulative potential : Study scientifically unjustified. Assessment Product is an inorganic gas with a low potential to bioaccumulate in aquatic species. 12.4. Mobility in soil : Because of its high volatility, the product is unlikely to cause ground or water pollution. Assessment Partition into soil is unlikely. 12.5. Results of PBT and vPvB assessment Assessment : Not classified as PBT or vPvB. 12.6. Endocrine disrupting properties Assessment : The substance/mixture has no endocrine disrupting properties.



12.7. Other adverse effects

Global warming potential [CO2=1]

13.1. Waste treatment methods

SECTION 13: Disposal considerations

Other adverse effects

Effect on the ozone layer

Effect on global warming

Safety Data Sheet

Nitrogen trifluoride

: 17200

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

: When discharged in large quantities may contribute to the greenhouse effect.

Ensure that the emission levels from local regulations or operating permits are not

: No known effects from this product.

: No effect on the ozone layer.

Contains greenhouse gas(es).

Contact supplier if guidance is required.

List of hazardous waste codes (from Commission Decision 2000/532/EC as amended)	 Ensure that the emission levels from local regulations of operating permits are not exceeded. Refer to the EIGA code of practice Doc.30 "Disposal of Gases", downloadable at http://www.eiga.eu for more guidance on suitable disposal methods. Discharge to atmosphere in large quantities should be avoided. Must not be discharged to atmosphere. Return unused product in original container to supplier. 16 05 04 *: Gases in pressure containers (including halons) containing hazardous substances.
13.2. Additional information	
	External treatment and disposal of waste should comply with applicable local and/or national regulations.
SECTION 14: Transport information	
14.1. UN number or ID number	
In accordance with ADR / RID / IMDG / IATA / ADN	. 2454
UN-No.	: 2451
14.2. UN proper shipping name	
Transport by road/rail (ADR/RID)	: NITROGEN TRIFLUORIDE
Transport by air (ICAO-TI / IATA-DGR)	: Nitrogen trifluoride
Transport by sea (IMDG)	: NITROGEN TRIFLUORIDE
14.3. Transport hazard class(es)	
Labelling	2.2 : Non flammable, non-toxic gases.
	5.1 : Oxidizing substances.
Transport by road/rail (ADR/RID)	
Class	: 2
Classification code Hazard identification number	: 20 : 25
Tunnel Restriction	: C/E - Tank carriage : Passage forbidden through tunnels of category C, D and E. Other
	carriage : Passage forbidden through tunnels of category E
Transport by air (ICAO-TI / IATA-DGR)	
Class / Div. (Sub. risk(s))	: 2.2 (5.1)
Transport by sea (IMDG)	
Class / Div. (Sub. risk(s))	: 2.2 (5.1)
Emergency Schedule (EmS) - Fire	: F-C
Emergency Schedule (EmS) - Spillage	: S-W

Messer Industriegase GmbH Messer- Platz 1 D - 65812 Bad Soden am Taunus Germany, +49 (0) 6196 7760-200



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

14.4. Packing group

14.4.1 dolling group	
Transport by road/rail (ADR/RID) Transport by air (ICAO-TI / IATA-DGR) Transport by sea (IMDG)	 Not applicable. Not applicable. Not applicable.
14.5. Environmental hazards	
Transport by road/rail (ADR/RID) Transport by air (ICAO-TI / IATA-DGR) Transport by sea (IMDG)	: None. : None. : None.
14.6. Special precautions for user	
Packing Instruction(s) Transport by road/rail (ADR/RID) Transport by air (ICAO-TI / IATA-DGR) Passenger and Cargo Aircraft Cargo Aircraft only Transport by sea (IMDG)	 P200. 200. 200. P200.
Special transport precautions	 Avoid transport on vehicles where the load space is not separated from the driver's compartment. Ensure vehicle driver is aware of the potential hazards of the load and knows what to do in the event of an accident or an emergency. Before transporting product containers: Ensure there is adequate ventilation. Ensure that containers are firmly secured. Ensure valve is closed and not leaking. Ensure valve outlet cap nut or plug (where provided) is correctly fitted.

14.7. Maritime transport in bulk according to IMO instruments

Not applicable.

SECTION 15: Regulatory information

15.1. Safety, health and environmental regulations/legislation specific for the substance or mixture

EU-Regulations

Restrictions on use Other information, restriction and prohibition regulations Seveso Directive : 2012/18/EU (Seveso III)	 None. Not listed on the PIC list (Regulation EU 649/2012). Not listed on the POP list (Regulation EU 2019/1021). Covered.
National regulations	
Water hazard class (WGK) Regulatory reference	 1 - Slightly hazardous to water. Ensure all national/local regulations are observed. Gesetz zum Schutz der arbeitenden Jugend (Jugendarbeitsschutzgesetz-JArbSchG) Betriebssicherheitsverordnung-BetrSichV TRBS 3145/TRGS 745 - Ortsbewegliche Druckgasbehälter – Füllen, Bereithalten, innerbetriebliche Beförderung, Entleeren TRGS 510 - Lagerung von Gefahrstoffen in ortsbeweglichen Behältern TRGS 407 - Tätigkeiten mit Gasen – Gefährdungsbeurteilung TRBS 2141 - Gefährdungen durch Dampf und Druck - Allgemeine Anforderungen. Classification for storage according to TRGS 510: 2A Gase (ohne Aerosolpackungen und Feuerzeuge). TA Luft. Vierte Verordnung zur Durchführung des Bundes-Immissionsschutzgesetzes (Verordnung über genehmigungsbedürftige Anlagen - 4. BImSchV) Anhang 2 Stoffliste zu Nr. 9.3 des Anhangs 1. Zwölfte Verordnung zur Durchführung des Bundes-Immissionsschutzgesetzes (12. BImSchV-Störfall-Verordnung).



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

15.2. Chemical safety assessment

A CSA has been carried out.

SECTION 16: Other information	n
Indication of changes	: Revised safety data sheet in accordance with commission regulation (EU) No 2020/878.
Abbreviations and acronyms	: ATE - Acute Toxicity Estimate.
	CLP - Classification Labelling Packaging Regulation; Regulation (EC) No 1272/2008.
	REACH - Registration, Evaluation, Authorisation and Restriction of Chemicals Regulation (EC) No 1907/2006.
	EINECS - European Inventory of Existing Commercial Chemical Substances.
	CAS# - Chemical Abstract Service number.
	PPE - Personal Protection Equipment.
	LC50 - Lethal Concentration to 50 % of a test population.
	RMM - Risk Management Measures.
	PBT - Persistent, Bioaccumulative and Toxic.
	vPvB - Very Persistent and Very Bioaccumulative.
	STOT- SE : Specific Target Organ Toxicity - Single Exposure.
	CSA - Chemical Safety Assessment.
	EN - European Standard.
	UN - United Nations.
	ADR - European Agreement concerning the International Carriage of Dangerous Goods by Road.
	IATA - International Air Transport Association.
	IMDG code - International Maritime Dangerous Goods.
	RID - Regulations concerning the International Carriage of Dangerous Goods by Rail. WGK - Water Hazard Class.
	STOT - RE : Specific Target Organ Toxicity - Repeated Exposure.
	UFI : Unique Formula Identifier.
Training advice	: Users of breathing apparatus must be trained.
-	Ensure operators understand the toxicity hazard.
Further information	: Classification in accordance with the procedures and calculation methods of Regulation
	(EC) 1272/2008 (CLP).
	Key literature references and sources of data are maintained in EIGA doc 169 :
	'Classification and Labelling Guide', downloadable at http://www.Eiga.eu .

Full text of H- and EUH-statements	
Acute Tox. 4 (Inhalation:gas)	Acute toxicity (inhalation:gas) Category 4
H270	May cause or intensify fire; oxidiser.
H280	Contains gas under pressure; may explode if heated.
H332	Harmful if inhaled.
H373	May cause damage to organs through prolonged or repeated exposure.
Ox. Gas 1	Oxidising Gases, Category 1
Press. Gas (Liq.)	Gases under pressure : Liquefied gas
STOT RE 2	Specific target organ toxicity – Repeated exposure, Category 2

DISCLAIMER OF LIABILITY

Before using this product in any new process or experiment, a thorough material compatibility and safety study should be carried out.
 Details given in this document are believed to be correct at the time of going to press.
 Whilst proper care has been taken in the preparation of this document, no liability for injury or damage resulting from its use can be accepted.



Nitrogen trifluoride

according to Regulation (EC) No. 1907/2006 (REACH) with its amendment Regulation (EU) 2020/878 Reference number: D-NF3-091

Annex to the safety data sheet

This Annex documents the Exposure Scenarios (ESs) related to the identified uses of the registered substance. The ESs detail protective measures for workers and the environment in addition to those described in sections 7, 8, 11, 12 and 13 of the SDS that are required to ensure that the potential exposure to workers and the environment remains within acceptable levels for each of the identified uses.

Table of contents of the Annex

Identified Uses	Es N°	Short title	Page
Formulation of mixtures in pressure receptacles	EIGA091- 1	Industrial uses, closed contained conditions	12
Transfilling in pressure receptacles	EIGA091- 1	Industrial uses, closed contained conditions	12
Feedstock in chemical processes	EIGA091- 1	Industrial uses, closed contained conditions	12
Electronic component manufacture	EIGA091- 1	Industrial uses, closed contained conditions	12



Nitrogen trifluoride

Annex to the safety data sheet Reference number: D-NF3-091 CAS-No.: 7783-54-2 Product form: Substance Physical state: Gas

1. EIGA091-1: Industrial uses, closed contained conditions

1.1. Title section

Industrial uses, closed contained conditions	
ES Ref.: EIGA091-1	
Revision date: 2/11/2018	

Environment	Use descriptors
CS1	ERC2
CS2	ERC6b

Worker	Use descriptors
CS3	PROC1

MEASE	Assessment method	Used ECETOC TRA model MEASE
-------	-------------------	--------------------------------

1.2. Conditions of use affecting exposure

1.2.1. Control of environmental exposure: ERC2

ERC2	Formulation into mixture
Product (article) characteristics	

Product (article) characteristics	
Physical form of product	See section 9 of the SDS, No additional information
Concentration of substance in product	≤ 100 %

Amount used, frequency and duration of use (or from service life)	
Annual site tonnage:	300
Emission Days (days/year)	100

Technical and organisational conditions and measures	
Wastewater emission controls are not applicable as there is no direct release to wastewater	
Soil emission controls are not applicable as there is no direct release to soil	
Ensure operatives are trained to minimise releases	
Use appropriate abatement systems to ensure that the emission levels defined by local regulations are not exceeded.	



Nitrogen trifluoride

Annex to the safety data sheet Reference number: D-NF3-091 CAS-No.: 7783-54-2 Product form: Substance Physical state: Gas

Conditions and measures related to sewage treatment plant		
No additional information		
Conditions and measures related to treatment of waste (including article waste)		
See section 13 of the SDS. No additional information		
Other conditions affecting environmental exposure		

Closed systems are used in order to prevent unintended emissions	
No additional information	

1.2.2. Control of environmental exposure: ERC6b

Г

ERC6b	Use of reactive processing aid at industrial site (no inclusion into or onto article)
-------	---

Product (article) characteristics	
Physical form of product	See section 9 of the SDS, No additional information
Concentration of substance in product	≤ 100 %

Amount used, frequency and duration of use (or from service life)	
Annual site tonnage:	50
Emission Days (days/year)	20

Technical and organisational conditions and measures	
Wastewater emission controls are not applicable as there is no direct release to wastewater	
Soil emission controls are not applicable as there is no direct release to soil	
Ensure operatives are trained to minimise releases	
Use appropriate abatement systems to ensure that the emission levels defined by local regulations are not exceeded.	

Conditions and measures related to sewage treatment plant	
No additional information	

Conditions and measures related to treatment of waste (including article waste)

See section 13 of the SDS. No additional information

Other conditions affecting environmental exposure	
Closed systems are used in order to prevent unintended emissions	
No additional information	



Nitrogen trifluoride

Annex to the safety data sheet Reference number: D-NF3-091 CAS-No.: 7783-54-2 Product form: Substance Physical state: Gas

1.2.3. Control of worker exposure: PROC1

PROC1	Chemical production or refinery in closed process without likelihood of exposure or
	processes with equivalent containment conditions

Product (article) characteristics	
Physical form of product	See section 9 of the SDS, No additional information
Concentration of substance in product	≤ 100 %

mount used (or contained in articles), frequency and duration of use/exposure	
The actual tonnage handled per shift is not considered to influence the exposure as such for this scenario. Instead, the combination of the scale of operation and level of containment/automation (as reflected in the technical conditions) is the main determinant of the process-intrinsic emission potential.	
Exposure duration	≤ 8 h/day
Covers frequency up to:	5 days/week

Technical and organisational conditions and measures	
Handle product within a closed system	
Apply a good standard of general or controlled ventilation when maintenance activities are carried out.	
See sections 2 and 7 of the SDS.	
Ensure operatives are trained to minimise exposure	
Ensure supervision is in place to check that the RMMs are in place and are being used correctly and that the OCs are being followed	

Conditions and measures related to personal protection, hygiene and health evaluation	
See section 8 of the SDS.	

Other conditions affecting workers exposure	
Indoor use	

1.3. Exposure estimation and reference to its source

1.3.1. Environmental release and exposure: ERC2

The exposure of aquatic, terrestrial, sediment and sewage treatment microorganisms is considered to be negligible because the substance partitions primarily to air when released to the environment.

1.3.2. Environmental release and exposure: ERC6b

The exposure of aquatic, terrestrial, sediment and sewage treatment microorganisms is considered to be negligible because the substance partitions primarily to air when released to the environment.



Nitrogen trifluoride

Annex to the safety data sheet Reference number: D-NF3-091 CAS-No.: 7783-54-2 Product form: Substance Physical state: Gas

1.3.3. Worker exposure: PROC1

Route of exposure and type of effects	Exposure estimate	Assessment conditions	RCR
Inhalation - Long-term - systemic effects	0.029 mg/m ³		0.001
Inhalation - Acute - systemic effects	0.083 mg/m ³		0.002
Acute - Local - Inhalation	0.083 mg/m ³		0.002
Long term - Local - Inhalation	0.029 mg/m³		0.001

1.4. Guidance to Downstream User to evaluate whether he works inside the boundaries set by the ES

1.4.1. Environment

	Guidance - Environment	Check that RMMs and OCs are as described above or of equivalent efficiency
1	Guidance - Environment	Check that RIVINIS and OUS are as described above or of equivalent efficiency

1.4.2. Health

Guidance - Health	Guidance is based on assumed operating conditions which may not be applicable to all
	sites; thus, scaling may be necessary to define appropriate site-specific risk management
	measures. For scaling see : http://www.ecetoc.org/tra http://www.ebrc.de/industrial-
	chemicals-reach/projects-and-references/mease.php

End of document